

	COMMERCIAL NAME	INCI NAME	%
A1	DEMINERALIZED WATER	AQUA	49,88
A2	DISODIUM EDTA	DISODIUM EDTA	0,02
A3	BUTYLENE GLYCOL	BUTYLENE GLYCOL	5,00
B1	UVINUL MC 8	ETHYLHEXYL METHOXYCINNAMATE	7,00
B2	UVINUL A PLUS	DIETHYLAMINO HYDROXYBENZOYL HEXYL BENZOATE	2,00
B3	NEO HELIOPAN E 1000	ISOAMYL P-METHOXYCINNAMATE	2,00
B4	PARSOL EHS	ETHYLHEXYL SALICYLATE	4,00
B5	DOWSIL FZ-3196 FLUID	CAPRYLYL METHICONE	3,00
B6	DERMOFEEL BGC	BUTYLENE GLYCOL DICAPRYLATE/DICAPRATE	2,00
B7	STEROL B125	C12-15 ALKYL BENZOATE	2,00
B8	SPAN60	SORBITAN STEARATE	0,50
B9	OLIVOIL EMULSIFIER FOKSNAB	POTASSIUM OLIVOYL HYDROLYZED WHEAT PROTEIN, CETEARYL ALCOHOL, GLYCERYL STEARATE, GLYCERYL OLEATE	4,00
B10	DOWSIL EL-7040 HYDRO ELASTOMER BLEND	CAPRYLYL METHICONE, PEG-12 DIMETHICONE/PPG-20 CROSSPOLYMER	2,00
C	SUNCLEAR T40AQ	TITANIUM DIOXIDE, ALUMINIUM HYDROXIDE, HYDRATED SILICA, DISODIUM STEARYL SULFOSUCCINAMATE, AQUA	10,00
D	KELTROL F	XANTHAN GUM	0,10
E	EPITEX 99 POLYMER	ACRYLATES COPOLYMER, ACRYLATES/POLYTRIMETHYLSILOXYMETHACRYLATE COPOLYMER	2,50
F	ACULYN SILTOUCH RHEOLOGY MODIFIER	SODIUM ACRYLATE/SODIUM ACRYLOYLDIMETHYL TAURATE COPOLYMER, DIMETHICONE, TRIDECETH-6, PEG/PPG-18/18 DIMETHICONE	2,00
G	HYDROLITE 6	1,2-HEXANEDIOL	2,00
H	PRESERVATIVES, PARFUM and pH REGULATOR	PRESERVATIVES, PARFUM and pH REGULATOR	AS NEEDED
I	STABILIZER/THICKENER	STABILIZER/THICKENER	AS NEEDED

Mix the ingredients of phase A until a limp, transparent solution is obtained.

Heat phase A to a temperature of 75°C +/- 1° C mixing.

Mix the ingredients from B1 to B4 and heat them to a temperature of 85° +/- 1°C. Add the ingredients from B5 to B10, mix until all solids are melt and the phase is homogeneous. Keep at a temperature of 80° +/- 1°C.

When the indicated temperatures have been reached, add phase B to phase A while stirring and homogenizing.

After the union, continue to stir and homogenize for about 10 minutes. Add phases C and D, stirring and homogenizing after every addition. Cool the product to a temperature of 40°C, then add the phases E, F and G one by one, homogenizing for a few minutes after every addition.

Stop homogenizing and continue stirring until the emulsion reaches room temperature.

Add preservatives, parfum and pH regulator as much as needed to set the pH.

In the end, add STABILIZER/THICKENER as much as needed to get the desired viscosity.